



■ SQUARE VALVES ● ROUND VALVES

We have easy ways to prevent material shearing, vent pressurized air or protect workers' precious fingers. Check out our accessories for rotary airlock valves.

INLET SHUNT WITH TIP CLEANER

Prevent wood dust jams in the rotor clearances.



■ ●

■ ●

DISCHARGE FINGER GUARD

Cover an open valve discharge to keep workers safe.



■ ●

■ ●

INLET SHEAR PROTECTOR

Keep material from shearing or jamming in the rotor clearances.

SPOOL STYLE



■ ●

■ ●


HALF-MOON STYLE



■ ●

■ ●


SPOOL STYLE - VENTED



■ ●

■ ●

SPOOL STYLE - ADJUSTABLE



■

DISCHARGE BLOW-THROUGH ADAPTER

Connect the valve discharge to a pneumatic or vacuum conveying line.



■ ●

■ ●

VENT BOX

Release air from a pneumatic conveying system.



■ ●

■ ●

MAINTENANCE SLIDE GATE

Slide open or closed to control material flow in gravity-feed applications.

AIR OPERATED



■ ●

■ ●

MANUALLY OPERATED



■ ●

■ ●